


Writer509-USB



TOP VIEW

- | | |
|-------|--------|
| USB-B | ICSP |
| 1:Vcc | 1:GND |
| 2:-D | 2:TVpp |
| 3:+D | 3:TVdd |
| 4:GND | 4:NC |
| | 5:PGD |
| | 6:PGC |